



**UNPACKING AND IDENTIFYING PARTS**

Remove the parts one at a time from the box, and make a check in the space provided as you identify each part. Any part that is packed in an envelope should be kept in that envelope after you identify it until it's called for. Do not throw away any packing material until all parts are accounted for. If anything is missing, please contact Tiffen for a replacement.

To order additional replacement parts see the enclosed parts list.

**Standard Parts**

*Steadicam JR, including Monitor (with normal stop block installed).*

*The Steady Stand may be used to support the camera during balancing, to avoid tiring your arms. The procedure described in this manual does not make use of it. If you use the Steady Stand, place it at the edge of a level table and secure the base of the Stand with gaffer's tape or other heavy-duty tape. Do not use without firmly securing to the table. Allow room under the table for the Lower Spar to swing without obstruction. When the JR is in flying mode, the hole in the bottom of the Grip will fit onto the Steady Stand.*



*The Steady Stand is designed to aid in balancing the JR*

- VHS video: "The Art of Steadicam JR"—Version 2.0.*
- Counter weights: 2 large, 2 small, 1 extra small.*
- Spare 'Obie' light bulb. (optional)*
- Mounting screws for mounting camcorder to JR (1 long, 1 short).*
- Locating pin set. Four different sizes, numbered 1-4 on the plastic "tree". Leave them on the tree for now.*
- Spare 'light' and 'heavy' stop blocks with screws (for use with various weight cameras).*
- Velcro strip. This is to provide optional cushioning and support as required by some cameras.*
- Rubber stabilizing wedge for further stiffening the camera mounting surface as required.*
- Spare Spar hinge cover.*