



-
- Note which hole on the Stage most nearly lines up with the threaded mounting hole on your camera. If you are between two holes, the one to the rear of this point on the Stage will be a good starting guess as the correct hole for your camera. Circle it with the grease pencil.*
 - Compare the locating pins with the locating pin hole in the base of your camera, and select the one that fits best.*
 - Mount this locating pin directly ahead of the mounting hole you have selected.*
 - Mount the camera as described in Section 6.*
 - When it comes to selecting the camera mounting screw, try the long screw first. DO NOT OVER TIGHTEN. If the mounting hole on your camera is too shallow, the screw will tighten into the camera without clamping it to the Stage.*
 - If this is the case, switch to the shorter mounting screw. Be careful not to over stress the camera mounting hole insert on your camera; it could pop out.*
 - Perform rough X-Y trim as described in section 7.*
 - Perform Z axis trim and fine X-Y trim as described in section 7.*

<p>When the unit is in satisfactory trim, proceed to section 9 of the videotape, "Activating the Monitor." Then continue with the Set-up Guide.</p>
--